




AT Commands Set

SIM900_GSM_LOCATION_ATC



Document Title:	SIM900 GSM Location AT Commands Set
Version:	1.00
Date:	2011-01-26
Status:	New
Document Control ID:	SIM900_GSM_LOCATION _ATC_V1.00

General Notes

SIMCom offers this information as a service to its customers, to support application and engineering efforts that use the products designed by SIMCom. The information provided is based upon requirements specifically provided to SIMCom by the customers. SIMCom has not undertaken any independent search for additional relevant information, including any information that may be in the customer's possession. Furthermore, system validation of this product designed by SIMCom within a larger electronic system remains the responsibility of the customer or the customer's system integrator. All specifications supplied herein are subject to change.

Copyright

This document contains proprietary technical information which is the property of SIMCom Limited., copying of this document and giving it to others and the using or communication of the contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages. All rights reserved in the event of grant of a patent or the registration of a utility model or design. All specification supplied herein are subject to change without notice at any time.

Copyright © Shanghai SIMCom Wireless Solutions Ltd. 2011

Version History

Version	Chapter	What is new
V1.00	Origin	

1 Introduction

This document presents the AT command of GSM location operation for SIM900. This document can apply to the same series of the modules which contain GSM location function, like SIM900, SIM900D, SIM900B and SIM900A.

1.1 Features

1.2 Reference

[1] SIM900 AT Commands Set

2 2 AT commands

2.1 AT+CIPGSMLOC

AT+CIPGSMLOC GSM Location and Time	
Test Command AT+CIPGSMLOC=?	Response +CIPGSMLOC: (1,2),(1-3) OK Parameter See Write Command
Write Command AT+CIPGSMLOC=<type>,<cid>	Response If <type>=1: +CIPGSMLOC:<locationcode>,<longitude>,<latitude>,<date>,<time> e> OK If <type>=2: +CIPGSMLOC:<locationcode>,<date>,<time> OK If error is related to ME functionality: +CME ERROR:<err>
	Parameter <type> 1 View the longitude, latitude and time 2 View time <cid> network parameters, refer to AT+SAPBR <locationcode> 0 Success If the operation failed, the location code is not 0, such as: 601 Network Error 602 No memory 603 DNS Error 604 Stack Busy 65535 Other Error <longitude> Current longitude in degrees <latitude> Current latitude in degrees <date> Format is YYYY/MM/DD, the time zone is GMT E.g. 2011/01/26

SIM900 GSM Location AT Commands Set

	<time> Format is hh/mm/ss,the time zone is GMT.E.g. 06:10:46
Reference	Note

3 Examples

SIM900 GSM location module provides GSM location solution. The following is the examples for application.

3.1 Activate bearer profile

```
AT+SAPBR=3,1,"Contype","GPRS" //Set bearer parameter
```

OK

```
AT+SAPBR=3,1,"APN","CMNET"
```

OK

```
AT+SAPBR =1,1 // Activate bearer context
```

OK

```
AT+SAPBR=2,1
```

```
+SAPBR: 1,1,"10.89.193.1"
```

OK

3.2 Get location

```
AT+CIPGSMLOC=1,1
```

```
+CIPGSMLOC: 0,121.354848,31.221402,2011/01/26,02:41:06
```

OK

```
AT+CIPGSMLOC=2,1
```

```
+CIPGSMLOC: 0,2011/01/26,03:12:58
```

OK

3.3 Deactivate bearer profile

```
AT+SAPBR=0,1 // Deactivate bearer context
```

OK

Contact us:

Shanghai SIMCom Wireless Solutions Ltd

Addr: Building A, SIM Technology Building, No.633, Jinzhong Road, Changning
District, Shanghai P.R. China 200355

Tel: +86 21 3252 3300

Fax: +86 21 3252 3301

URL: www.sim.com/wm